



# GTAG7 / GTAG7-SP AIRGUARD®

1




MARK CUTOUT LOCATION ON ACCESS FLOOR PANEL.

2




CUT ACCESS FLOOR PANEL WITH MANUFACTURERS RECOMMENDED METHOD. BE SURE TO FOLLOW ALL RECOMMENDED SAFETY PROCEDURES

3




CLEAN PANEL SURFACE, REMOVE ADHESIVE STRIPS AND PRESS FIT GROMMET INTO OPENNING. SCREW DOWN INSTALLATION IS OPTIONAL USING SUPPLIED FASTENERS. PILOT HOLES ARE RECOMMENDED

4




REMOVE SAFETY COVER AT CABLE INSTALLATION

5



USING A STANDARD SLOTTED DRIVER, REMOVE BRUSH CARTRIDGES TO INSTALL CABLES

6



SNAP BRUSH CARTRIDGES BACK INTO PLACE AROUND CABLES